

2-1/4" (door thickness) 1-3/4" 1-3/8"

Installation Template for E308-40, E308-50 Mortise Lock(85mm C~C)

240

Edge bore

Line for Strike

Face bore

E308-40

E308-50

209

E308-40 mortise 2-5/8" deep  
E308-50 mortise 3-1/4" deep

1"

3"

Through bolting hole for Lever x2  
dia 3/8"

152

Lever hole  
dia 7/8"

Fold on dotted line and attach to the door at desire height. Mark the position of necessary lines for Face and Edge bore. Please read this Template and the Trim set installation menu carefully before drilling and mortising the door.

85mm

Cylinder hole  
dia 7/8" drill twice

68

59

50

dia 3/8"

Line for Strike

1.5" (38.1mm)

31

dia 3/4"

40 R 50 R 40 C 50 C 40 L 50 L

21 31 40 50 59 69

Face bore/ Entrance function illustrated.

Check the drawing measurements if reprint



